



## PRODUCT SPECIFICATION – Wake up clock



### Features:

Alarm clock with two-tone alarm, infinite snooze function, key-lock and built-in background light. The inner segment flashes every second.  
On the above Wake up clocks the time is 11.15 or 23.15.

### Operating FRONT PANEL:

#### V ALARM SET

- Time mode, a short press: A short press displays the set alarm time for five seconds whereafter the Wake up clock automatically reverts to normal time.
- Time mode, press and hold: Press and hold for more than two seconds to set the alarm time.
- Time- or alarm setting mode, short press: Decreases time at time- or alarm setting by one minute per press.
- Time- or alarm setting mode, press and hold: Press and hold for one second in order to decrease the time faster.

#### TIME SET ▲

- Time mode, a short press: A short press displays the set alarm time for five seconds whereafter the Wake up clock automatically reverts to normal time.
- Time mode, press and hold: Press and hold for more than two seconds to set the time.
- Time- or alarm setting mode, short press: Increases time at time- or alarm setting by one minute per press.
- Time- or alarm setting mode, press and hold: Press and hold for one second in order to decrease the time faster.

### Operating TOP PANEL:

#### ON

- Time mode, a short press: Activates the built-in background light for five seconds.
- Time mode, press and hold: Press and hold for two seconds to activate the alarm (the alarm icon is displayed in the center of the clock).
- Alarm mode, a short press: Activates the snooze function in intervals of eight minutes and the built-in background light for five seconds when in alarm mode.

#### OFF

- Time mode, a short press: Activates the built-in background light for five seconds.
- Time mode, press and hold: Press and hold for two seconds to deactivate the set alarm.
- Alarm mode, a short press: Activates the snooze function in intervals of eight minutes and the built-in background light for five seconds when in alarm mode.
- Alarm mode, press and hold : Press and hold for two seconds to deactivate the alarm (the alarm icon disappears).

### Operating Battery compartment:

**Key lock On/Off:** Activates / deactivates the key-lock.



Alarm icon in the center of the clock.

- stationary: The alarm is activated, when the icon is displayed.
- flashes: The icon flashes when the alarm sounds or the snooze-function is activated.

**Batteries:** Two pcs. "AAA" batteries.

**Material:** ABS, PMMA and steel.

**Colours:** Anthracite or silver.

**Dimensions:** 76 x 62 x 25 mm

**App. weight:** 152 g